

Jr. Footlight™ 550

Medium

Shoe Size	Tele Tone® Tap (Toe)	Shoe Size	Duo Tone® (Heel)
4-5.5	5	4-7.5	7
6-9	3	8-11	6
9.5-11	2		

Wide

Shoe Size	Tele Tone® Tap (Toe)	Shoe Size	Duo Tone® (Heel)
5-7.5	3	4-7.5	7
8-10	2	8-11	6
10.5-11	1		

Student Footlight™ 650

Medium

Shoe Size	Tele Tone® Tap (Toe)	Shoe Size	Duo Tone® (Heel)
4.5-7	4	4-7	8
7.5-10	5	7.5-8	7
		8.5-10	6

Wide

Shoe Size	Tele Tone® Tap (Toe)	Shoe Size	Duo Tone® (Heel)
5-10	5	4.5-7	8
		7.5-10	7

Theatrical Footlight™ 656

Medium only

Shoe Size	Tele Tone® Tap (Toe)	Shoe Size	Duo Tone® (Heel)
5-10	5	5-10	10

Tele Tone® Tap (Toe) = **CZTTT** ; Duo Tone® (Heel) = **CZDT**